KIRK 50XX HANDSET

Service Codes for KIRK 50XX Handset

Some of the given codes might not be active as the level of service codes implemented is depending on the hardware & software status of the handset.

To enter a Service Code - enter the requested code and press OFF-HOOK key.

- *99950* Delete phone book, speed dial list, message templates and all subscriptions
- *99951* Delete Phonebook and speed dial list
- *99954* Delete all subscriptions
- *99968* Enable B-answer when placed in charger
- *99977* Vibrator, buzzer and display test
- *99988* Show handset up-time
- *99989* Test display for measuring radio performance/coverage